

MICROLON PRODUCTS

AWARD WINNING METAL TREATMENT TECHNOLOGY



INBOARD STERNMOUNT

This is the only set of instructions you will need to install Microlon Engine Treatment. The Engine Only treatment instructions are covered step-by-step on this page. It is recommended that you carefully read all instructions prior to installation.

- 1. Oil Change.** Change the oil before installing the Microlon Engine Treatment. After treating your engine with Microlon, do not change the oil for at least 1,000 miles. Regular oil change in accordance with your vehicle's recommended schedule is best.
- 2. Shake Well.** Shake Microlon products thoroughly before adding to engine. The Microlon resin is held in suspension only after being shaken up from the bottom of the can. Start engine and let it run until it reaches normal operating temperature.
- 3. Add 8 oz Microlon Fuel Treatment.** Microlon liquid treats the top of your engine through the fuel system. Make sure to shake the Fuel System Treatment well before adding to a **¼ full or less** fuel tank.
- 4. Add Microlon to the crankcase.** Microlon engine treatment treats your engine through the oil. The Microlon Treatment works best when added to a running engine. To add Microlon to a running engine, use the injector bottle included with the kit or funnel to add Microlon fluid through the dipstick opening.
- 5. Drive for at least one hour.** The Microlon treatment needs this time to cleanse the engine so that the film that provides the savings and protection can form in the engine.

Outdrive:

- 1.** Shake well.
- 2.** Add Microlon Compound 90 to the outdrive.

Microlon Products

6601 Burroughs Avenue ~ Sterling Heights, MI 48314
(586) 803-9393 ~ fax (586) 803-1545
www.microlonproducts.com